



Rod Pocket / 3" Flange Rod Pocket / Classic Tab / Back Tab Installation Instructions

Getting Started

Carefully read all instructions before you begin installation. Please make sure that you have your rod drapery hardware mounted to the wall.



Installation Instructions

1. Insert your drapery hardware through the rod pocket at the top of the drapery

(Repeat for all other panels)

2. Once the draperies are in place, install the rod onto the wall mounted hardware

3. Space out the folds to achieve the desired look



Drapery Care

Once the draperies are installed most wrinkles and folds will hang out on their own within 1 - 2 weeks. A garment / commercial steamer may also be used to help smooth out the wrinkles. Certain fabrics like silks or linens have natural characteristics that steaming won't remove.

Questions?

Our dedicated customer service team is available to answer any questions about your drapery. Contact us at 347-727-0490 or email service@glamoureauxdesigns.com

